



1. Insert SD memory card (right side) and three AA batteries (back)
2. Press-and-hold **HOME**  to power-on.
3. Check charge level (screen top right)
4. Point the microphones inward for close-up recording, outward to capture more ambient sound
5. Set **EXT IN** to **MIC** (left side) and plug in a set of earphones (**LINE OUT**)
6. Check input volume level
  - a. Press **RECORD** for standby (light flashes)
  - b. Volume should peak at dark tick mark
  - c. Adjust **INPUT LEVEL** (left side) **+** or **-**
7. Recording
  - a. **PLAY** - start /restart (**RECORD** light steady)
  - b. **RECORD** - pause (light flashes)
  - c. **HOME** - stop



Use the earphones and listen for unwanted noise.



8. Press-and-hold **HOME** to power-off
9. **Remove your SD card!**

### Transferring files to a computer

- Plug the SD card directly into a computer
- OR Use an SD card reader
- OR use a USB cable (supplied with recorder)
  - o Connect cable to recorder and computer
  - o Recorder appears as USB storage drive
  - o Drag files from recorder to computer
  - o Eject recorder from computer





## Using the menus

Press **MENU** to start  
+ and - move up and down a list  
|<< and >>| select an option  
ENTER makes a choice  
MENU returns to a previous menu screen  
HOME returns to the main screen

---

## Restore factory settings (initialize)

From the **MENU** choose **OTHERS**, then **SYSTEM**  
Select **INITIALIZE** and highlight **Exec**  
Press **ENTER** to confirm, **ENTER** again to initialize  
(HOME will cancel)

## Record MP3 (not WAV)

From the **MENU** choose **REC SETTING**  
Select **FORMAT** and highlight **MP3 320k**  
Press **MENU** again to go back to the main screen

## Turn speakers on/off

From the **MENU** choose **SPEAKER**

## Adjust output volume (speaker or earphones)

From the **HOME** screen press + or -

## Listen to a recording

From the **MENU** choose **BROWSE**  
Select a recording  
Press **HOME** to stop, **PLAY** to start

## Set date and time

From the **MENU** choose **OTHERS**  
Select **DATE/TIME**  
+ and - change a number  
|<< and >>| select an item  
Press **ENTER** when finished